




**BOUNDARY GARD™
BX-80NR**



OPTEX

**BX-80NRi
Wiring Guide**



<u>Harness Wiring</u>	<u>EN1941</u>
WHITE	PRIMARY ALARM- N/C Detector Alarm
BLACK	NEGATIVE/ALL COMMONS/SHARED
RED	POSITIVE POWER/SHARED
BROWN	RESET INPUT/NOT USED
BLUE	TAMPER INPUT/Detector Tamper
GREEN	SECONDARY ALARM-NOT USED

(Low Battery is built into EN1941 and Shared with Detector Power)

OPTEX INCORPORATED (USA)
13661 Benson Ave Bldg C
China CA, 91710 U.S.A
TEL: 909-9935770
Tech: (800) 966-5770
URL: <http://www.optexamerica.com>