


# Warranty



- 1. Name of the product.
- 2. Model number of the product.
- 3. The area of problem.
- 4. Phone number and address at which you can be contacted.

## Warranty Card

| PRODUCT         |  |
|-----------------|--|
| MODEL           |  |
| DATE PURCHASED  |  |
| WARRANTY PERIOD |  |
| AGENCY ADDRESS  |  |

# **NOCOM** Warranties the original purchaser of this product as follows.

- 1) This product is produced under strict quality control and inspection procedures.
- 2) If this product breaks down during proper use as a result of product defect, KOCOM will repair it within one year from date of purchase free of charge.
- 3) The following cases will be subject to charge, even during warranty period:
- a. Breakdown during transport, or through careless treatment, by consumer.
- b. Breakdown cause by unauthorized repair, or system modification.
- c. Breakdown caused by natural disaster or power disorder.



http://www.kocom.com

E-mail: export@kocom.co.kr

This manual is based on the date as shown in the right and specifications are subject to change without notice for quality improvement

KIP-300 11.03.23

# KIP-300 MANUAL

# **INTERPHONE**


- ■2-wire Non-Polarity
- Slave Interphone



Thank you very much for your purchasing of our product, Please read carefully before operating and then keep it, Thank you,


KOCOM CO.,LTD.

## Name of Devices




## How to Install


#### ■ Interphone Installation



- 1 Install an "Interphone Wall-mounting Tapestry" on a wall.
- 2 Connect a "Slave Connector" to the wire installed.
- 3 Connect a "Slave Connector" to the connector on the backside of an interphone.
- [4] Install an interphone on an "Interphone Wall-mounting Tapestry" and then fix it.

## Wiring Diagram






- To connect a wiring code to a terminal, loose a screw, connect the end of a cord to the bottom of the screw and then fix it,
- To fix a wiring code, fix it with a stapler not to damage the cord.
- To use the existing wire, be careful of disconnection and short circuit,

## **Product Functions**


| Model No.            | KIP-300                    |
|----------------------|----------------------------|
| Input Power          | supplied by DC 24V Slave.  |
| Power Consumption    | Under 2W during Operation  |
| Call Mode            | Handset Call               |
| Wiring Specification | 2-Wire(slave) Non-Polarity |
| Size                 | (W)75mmX(H)176mmX(D)52mm   |

# Product Composition



## How to Operate

#### ■ Paging and Calling from a Slave to Interphone



## ■ Paging and Calling from an Interphone to a Slave

