



	SERIE PURPLE							SERIE GOLD						
	WD10PURZ	WD20PURZ	WD30PURZ	WD40PURZ	WD60PURZ	WD80PURZ	WD100PURZ	WD1005FBYZ	WD2005FBYZ	WD4002FYYZ	WD6002FRYZ	WD8003FRYZ	WD101KRYZ	WD121KRYZ
DS115j	X	X	X	X	X	X	X	X	X	X	X	X	X	X
DS218j	X	X	X	X	X	X	X	X	X	X	X	X	X	X
DS718+					X					X	X		X	X
DS918+					X					X	X	X	X	X
DS1517+	X	X	X	X	X	X	X			X	X	X	X	X
DS1817+	X	X	X	X	X	X	X			X	X	X	X	X
DS2415+	X	X	X		X	X	X	X	X	X	X	X	X	X
DS3018xs					X					X	X	X	X	X
DS3617xs	X	X	X	X	X		X	X	X	X	X	X	X	X
RS816	X	X	X	X	X	X	X	X	X	X	X	X	X	X
RS815+	X	X	X	X	X	X	X	X	X	X	X	X	X	X
RS2416+	X	X	X		X	X	X	X	X	X	X	X	X	X
RS3617xs	X	X	X	X	X	X	X	X	X	X	X	X	X	X
RS3617xs+	X	X	X	X	X	X	X	X	X	X	X	X	X	X
RS4017xs+	X	X	X	X	X	X	X	X	X	X	X	X	X	X
RS18017xs+					X		X			X	X	X	X	X
DX513	X	X	X	X	X	X	Incompatible	X	X	X	X	X	X	X
DX517					X	Incompatible	X	Incompatible	Incompatible	X	Incompatible	X	X	X
DX1215					X	Incompatible	X	Incompatible	Incompatible	X	Incompatible	X	X	X
RX415	X	X	X	X	X	X	Incompatible	X	X	X	X	X	X	X
RX1217				X	Incompatible	Incompatible	X	Incompatible	Incompatible	X	Incompatible	X	X	Incompatible
RX1217sas					X	Incompatible	X			X	X	X	X	X